




## Removing and installing glove box/knee protection

<p><b>3409</b></p> 	<p><b>VAS 6223/9</b></p> 
<p><b>T10057</b></p> 	
	<p>G68-0001</p>

### Special tools and workshop equipment required

- ◆ Removal wedge -3409-
- ◆ Protective cap -VAS 6223/9-
- ◆ Radio release tool -T10057-

## Removing


- Disconnect battery on vehicles with knee airbag → Rep. Gr.27.




### **WARNING**

Observe safety precautions for working on airbags → Chapter.

- Use screwdriver to prise off right dash panel end trim -arrow-.



- If fitted, remove CD changer as follows:
  - Insert two keys of radio release tool -T10057- into front of CD changer.
  - ◆ Top L - top left
  - ◆ Top R - top right
  - Pull CD changer out of mounting frame.
  - Unplug electrical connector.
  - Unplug connector for optical fibre.



Cover open wiring harness connector -2- of optical fibre cable with protective cap -VAS 6223/9-- Item 1-.




### **Note**

The protective cap is designed to prevent the end face of the optical fibre from becoming soiled or damaged, as this would impair light transmission.


Press catches on CD changer and

- pull release keys out of CD changer.




If fitted, remove storage compartment from glove box. To


- do so, use small screwdriver to release retaining tabs -1- and -2- in -direction of arrow-.
- Pull storage compartment out of glove box.



- Remove bolts -arrows-.
- Remove bolts -1- and -2-.



- Unplug electrical connector -1- for glove box wiring harness -2- from supply lead -3-.



- On vehicles with knee airbag: Pull catch -2- in direction of arrow and unplug electrical connectors -1- and -3-.
- Remove glove box.

#### Installing

Installation is carried out in reverse order; note the following:

- Connect battery. Measures to be taken → [Rep. Gr.27](#)

Tightening torque:

Glove box to dash panel: 4 Nm

